



Connect and secure each BNC cable to the back of the DVR. Each channel has one input for Audio and one for Video.

Audio Source



BNC Cables




Monitor

Connect to CCTV Monitor

Speakers

Use optional speakers to hear live audio



Power

Connect to UPS or power strip

Microphone

Use optional microphone to talk to client DVRs

VGA Monitor

Use optional VGA monitor to view live video

Keyboard

Use for optional Control Keyboard

DVR Link

Use to link additional DVRs

Pan Tilt Zoom Camera

Use to connect optional PTZ Cameras

Network

Connect to router for optional remote viewing

ON/OFF Switch